

360° rotation dual camera Pipe inspection camera



Please read the manual carefully before operating the system.

Please charge the battery before using.



MANUAL

Catalog



SAFETY AND NOTICE	3
1. PARTS LIST	4
1.1. ACCESSORIES	4
1.2. CONTROLLER	5
2. QUICK START GUIDE.....	6
2.1. CONNECTION	6
2.2. ASSEMBLING SKID.....	7
2.3. CHARGE THE BATTERY	8
2.4. STARTING UP	8
3. MENU	10
3.1. PLAY VIDEO.....	10
3.2. PLAY PHOTO.....	10
3.3. VIDEO SETTINGS	11
3.4. SYSTEM SETTINGS	12
4. KEYBOARD (OPTIONAL)	15

Safety and Notice



Warning

To avoid electrical shock put the item indoor when charging



Warning








Use only input AC 100~240V output DC 12.6V charger.

This machine can only use the original charger and lithium battery, reminding the charging time is 5 hours. Please charge the battery before use!


1. Please check the appearance and functionality of the goods upon receipt. In the event of damaged or missing goods, please forward images to us within 3 working days, Otherwise, we will not be able to provide after-sales service
2. Working environment of camera system -10°C~50°C(14°F~122°F)≤95% RH; Storage environment: -20°C~70°C(-4°F~158°F) ≤95% RH.
3. The warranty becomes void if any physical damage is present by user or force majeure factors or if the system is disassembled or connect non-factory parts by the user
4. Do not disconnect the SD card while recording or playing as this may damage the system and/or the SD card
5. Remember to always back up the data on your SD card
6. Before using the SD card for the first time, it is recommended to use the check system to format the SD card.
7. Remember to slide the write protection tab to the unlocked position. Otherwise, all data on the SD card is protected and cannot be edited or formatted.
8. Use only the original accessories to avoid possible risks to health and property, and thus meet all related legal regulations.
9. Keep controller dry.
10. Do not drop, knock, or shake the inspection system. Inappropriate behavior when using the camera system may damage the internal electronic circuit board or deform the lens shape.
11. Make sure all accessories are connected before starting up.
12. Do not remove or install camera, keyboard, coil, SD card and other accessories when the machine is turned on. If replacement is required, please replace it in the power off state.

1. Parts list

1.1. Accessories

Item	Image	Description	Optional
Controller Box		<ul style="list-style-type: none"> ● 7 inch Screen ● Monitoring & Video recording ● Storage medium: 8G SD card & card reader (max 256G) 	Standard
visor		<ul style="list-style-type: none"> ● Size : 198.5*94*68mm ● Material: engineering plastic 	Standard
Cable Wheel		<ul style="list-style-type: none"> ● Size: ø330mmX132mm ● Cable material: fiberglass wire ● Cable length: 13m ● Cable diameter: Ø7mm ● Built-in battery:11.1V 4400mAh 48.84Wh 	Standard
Camera head		<ul style="list-style-type: none"> ● Size: ø23*80mm ● Rotation:panning 360 ° 	Standard
Suitcase		<ul style="list-style-type: none"> ● Size: L440*W395*H165mm ● Material: Fire board & Aluminum alloy 	Standard
Charger		<ul style="list-style-type: none"> ● Input: AC100-240V~50 / 60Hz ● Output: DC 12.6V / 1000mA ● Plug specifications:5521 	Standard
SD card & Card reader			Standard
Waterproof Ring			Standard
Manual			Standard
Screw Driver			Standard






1.2. Controller



1	ON/OFF	13	SD Card Slot
2	Menu	14	Power indicator
3	Back	15	Keyboard USB port
4	UP/ZOOM+	16	USB port
5	Left/ backward	17	No function (reserved)
6	Right/ fast forward	18	microphone
7	Down/ZOOM-	19	Camera inversion
8	Photo/OK/ Photo folder	20	Camera switching
9	Quick playback	21	Camera forward rotation
10	Record	22	Headphone jack
11	Light brightness down	23	DC JACK
12	Light brightness up	24	Video output


2. Quick Start Guide

2.1. Connection

<p>1. Install the sun visor.</p> 	<p>2. Loose the break.</p> 	<p>3. Put the wire into the wire hook</p> 
<p>4. Connect the camera head to the coil</p> 	<p>5. The installation is complete.</p> 	

WARNING:

1. Check the waterproof ring between all connections.
2. Do not hold the rotatable parts when installing the camera.



2.2. Assembling SKID

2.2.1. Install 40mm SKID

<p>1. Install the camera into the SKID</p> 	<p>2. Tighten the screws on the outside of the skid to fix the skid.</p> 	<p>3. The skid is installed.</p> 
-------------------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------

2.2.2. Install 80mm SKID

<p>1. Install the camera into the SKID</p> 	<p>2. Tighten the screws on the outside of the skid to fix the skid.</p> 	<p>3. The skid is installed.</p> 
--------------------------------------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------

Be careful:













The mounting SKID must not exceed the rotatable portion.





2.3. Charge the battery



Charge the Battery

<p>1. Connect the adapter to a power supply.</p> 	<p>2. Connect the plug to the port of the Controller</p> 	<p>3. The indicator will change from red to green when finished charging.</p> 
------------------------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------

2.4. Starting up


<p>1. . Insert SD Card Insert SD card or card reader & SD card.</p> 	<p>2. Long press the power button to turn on.</p> 	<p>3. Record video Press this button to record, press again to stop recording.</p> 
<p>4. Take photo & playback Press this button to take photo. Long press button to playback.</p>  	<p>5. Audio and text record (Optional) Support to record audio by microphone and input text by keyboard when recording video</p> 	<p>6. Zoom in and out Press these two buttons to zoom in and zoom out image when recording.(max 8 levels)</p>  <p>When playing a video, you can use these two buttons to adjust the volume</p>
<p>7. Adjust volume When recording a video, you can use these two buttons to adjust the volume</p>  <p>When playing a video, press these two buttons to fast forward/rewind.</p>	<p>8. Adjust lights of camera Press these two buttons to adjust the light.</p>  	<p>9. Camera rotation Press these two buttons to rotate the camera</p>  

<p>10. Camera switch Press this button to switch between front/side cameras</p> <div>C1 C2</div> <div></div>	<p>11.Play video Press these two buttons to play video.</p> <div><div>PLAY BACK</div><div>OK</div></div> <div></div>	<p>12.Delete video Press these buttons to delete video.</p> <div><div>MENU</div><div>are you sure want to delete this photos?</div><div>Delete</div><div>Cancel</div></div>
<p>13.CVBS video out Long press the menu button for 3 seconds to switch the screen connected to other RCA jacks. Operate in the same way to turn off this feature</p> <div></div>		





When play back video, press  button to pause the video, and press  buttons to fast forward and backward the video.

WARNING:


- ◆ Pay attention to the direction of the SD card.
- ◆ Do not use "USB STICK" and "SD card" at the same time.
- ◆ Do not insert or remove the U disk or SD card during the photo/video process.




3. Menu

Press  to enter menu. Press  to choose the items. Press  to enter submenu. Press  to enter upper submenu until to homepage.


Play Video




Play Photo



Video settings





System settings



3.1. Play Video

The video folder can be opened in the menu, or it can be opened quickly by pressing "PLAY BACK".



- "OK" button to play the video, "◀▶"backward/ Fast forward , "▲▼"adjust the volume , "MENU" button to delete the video.



3.2. Play Photo

The photo folder can be opened in the menu, or you can press and hold the "OK" button for 3 seconds to quickly open it.


- "OK" button to view photos, "MENU" button to delete photos.



3.3. Video settings


3.3.1. Set the length of time to record video

- 5 minute
- 15 minute
- 30 minute




3.3.2. Record Audio

- ON
- OFF




3.3.3. CVBS output

- NTSC
- PAL




3.3.4. Mic volume

- First press the OK key, press the left and right keys to adjust the volume



3.3.5. Time Stamp



- ON
- OFF



3.4. System settings


3.4.1. Picture

- Brightness
- Contrast
- Chroma
- Reset




3.4.2. Volume

- Press the left and right keys to adjust the volume



3.4.3. Language


- Press the up and down keys to set the language



3.4.4. Time



Date and time

Press the up and down keys to set the date and time, and press the left and right keys to select the time and date





3.4.5. Default Setting

- No: Cancel
- Yes: Confirm




3.4.6. Format

- No: Cancel
- Yes: Format SD card(Note: please back up the data in the SD card before operation)





3.4.7. Firmware update

- No: Don't upgrade system
- Yes: Start to upgrade (Need to insert the SD card with the upgrade program, press the "OK" button to upgrade.)




3.4.8. View software version

- View software version, date



4. Keyboard (Optional)



1. The font and character size have been set and cannot be changed.
2. The basic operation of characters is to automatically push back, covering the input characters on the image.
3. The cursor flashing indicates the current position of the character to be input on the screen. The cursor position can be controlled by the direction key on the keyboard. The cursor will move from left to right, from top to bottom and back. After typing a character, the cursor flashes quickly at the position of the next character, and then disappears. Press F6 to switch between cursor flashing and cursor clearing.
4. Video character overlay input uses a standard American keyboard. The alphabetic characters in the QWERTY area and the numeric characters of the keypad can be directly input to the screen. Normally, lowercase letters are entered. When you press and hold the shift key or press caps lock, you can enter uppercase letters. When exiting uppercase input, press caps lock again. Use the backspace key to move the characters on the screen, which will quickly replace the characters to the left of the cursor with blank characters, and the cursor will move to the left. The delete key on the keyboard does not give any function. Press enter to move the cursor to the start of the next line.

F6	The switch cursor flashes
F9	Clear screen
↑↓←→	Move cursor position
CTRL+1~8	Quick jump page

5. The video text superimposing unit displays it in the current screen page. The text written to these pages will be saved in the local nonvolatile memory until it is overwritten. To move between screen pages, use the page up and page down keys. To quickly jump to page 1 ~ 8, press Ctrl + X (x stands for 1 ~ 8). Supports up to 64 page editing. To clear the screen page of the text, press F9.